



Instructions for installing flexible stone



Step 1: Surface preparation

Before installing the flexible stone, it is necessary to carefully prepare the surface:

Surface cleaning: Remove dust, dirt, and oils.

Surface leveling: Eliminate any uneven areas using a leveling compound.

Priming: Apply a layer of primer to improve adhesion and allow it to dry.



Step 2: Applying the adhesive

After preparing the surface, apply the adhesive:

Adhesive preparation: Dilute the adhesive according to the manufacturer's instructions.

Applying the adhesive: Using a notched trowel, apply the adhesive evenly on small sections of the surface. Work with the adhesive gradually so it does not dry before placing the stone.



Step 3: Installing the flexible stone and finishing

Installing the stone: Start from one edge, pressing the stone onto the surface. Use a rubber roller to remove air bubbles.

Fitting and cutting: If necessary, adjust the size of the stone using a knife.



Finishing: Allow the adhesive to dry.

These three steps will help you successfully install flexible stone and create a durable, aesthetic finish.

